


Camera Housing

This document is an addendum to the **Camera Housing & Accessories Operating Instructions** and describes how to connect power to the AXIS 211 installed in the outdoor housing. Please read through both instructions carefully before proceeding with the installation.




Camera housing with AXIS 211 installed

Follow the instructions in the **Camera Housing & Accessories Operating Instructions** to install the Axis network camera.

Follow these instructions to connect power to the camera:

Connect the supplied cable from the power connector in the camera housing (3,4) to the I/O connector on the back of the camera (1,2).



Important!

Make sure that the + and - wires are connected correctly. If not, the camera may be damaged when power is applied.

This description applies to the following articles:

Item	Part no.
VT Power Supply OHEPS19	0217-011
VT Verso Housing HPV42K1A000	0217-001
AXIS 211 Network Camera	0198-00x



Powering
the
AXIS 211 Network Camera
in a Videotec Verso
Outdoor Housing