

## Camera Housing

This document is an addendum to the **Camera Housing & Accessories Operating Instructions** and describes how to connect power to the AXIS 221/223M installed in the outdoor housing. Please read through both instructions carefully before proceeding with the installation.




*Camera housing with AXIS 221/223M installed*

Follow the instructions in the **Camera Housing & Accessories Operating Instructions** to install the Axis network camera.

Follow these instructions to connect power to the camera:

Connect the supplied cable from the power connector in the camera housing (1,3) to the connector on the back of the camera (2,4).



No.	Color	Description
1	Black	Power connector GND (-)
2	Black	Camera GND (-)
3	Red	Power connector DC Power (+)
4	Red	Camera DC Power (+)

This description applies to the following articles:

Item	Part no.
VT Power Supply OHEPS19	0217-011
VT Verso Housing HPV42K1A000	0217-001
AXIS 221 Network Camera	0221-0xx
AXIS 223M Network Camera	0247-0xx

### Important!

Make sure that the + and - wires are connected correctly. If not, the camera may be damaged when power is applied.



**Powering  
the  
AXIS 221/223M Network  
Camera  
in a Videotec Verso**