


INSTALLATION GUIDE

AXIS T94F02L Recessed Mount




1x



1x




1x



1x



4x



1x

M25
3/4"






1x

M20
1/2"




1x







3




4




5




6






7




8









12




13




14





15



16





Installation Guide

AXIS T94F02L Recessed Mount

© Axis Communications AB, 2014

Ver.1.0

Printed: May 2014

Part No. 55462