










AXIS T94K01L Recessed Mount

Installation Guide


AXIS T94K01L Recessed Mount




AXIS T94K01L Recessed Mount



1



2




AXIS T94K01L Recessed Mount


3

M20 → M25
1/2" → 3/4"



- AXIS Q35 L=150 mm (6 in)
- AXIS P32 L=150 - 250 mm (6 - 10 in)
- AXIS P33 L=150 mm (6 in)




i



4










AXIS T94K01L Recessed Mount




5

4x







AXIS T94K01L Recessed Mount




8



9




10




AXIS T94K01L Recessed Mount


11





12





13




AXIS T94K01L Recessed Mount







AXIS T94K01L Recessed Mount






4



5




6




AXIS T94K01L Recessed Mount


7




8




9



10




11




AXIS T94K01L Recessed Mount


12





AXIS P3214-V
AXIS P3215-V





13






4x




14




AXIS T94K01L Recessed Mount




3




AXIS T94K01L Recessed Mount




4



5




6




AXIS T94K01L Recessed Mount

7



8



9

