


Installation Guide of the Bracket


How to install the bracket

1. Bracket can attachd in the both sides of the rack.
Bracket is set for attaching to right side of the rack upon delivery.
2. Attach the bracket to right side of the rack.
3. Tighten the bracket by turning two knob nut in the back of the bracket clockwise.
4. Decide the position of the bracket freely.




How to installing AXIS 7000/FX

For safety, use double-sided tape to fix AXIS 7000/FX and the bracket.




Attachment sectional view



How to adjust Tile plate

To fix the Tilt plate, there are screw holes on the back side of the bracket. Change the direction of the plate by removing the screw.



Caution!

- Do not use the bracket except installing AXIS 7000/FX.
- Do not lean against the bracket, or put heavy things.