


AXIS Device Manager Edge

Easy device management from anywhere

With AXIS Device Manager Edge, you can be sure your Axis products are always up-to-date and protected. For instance, it offers automatic upgrades, so your devices always get the latest software releases. For any manual management tasks, this cloud-based software is accessible from anywhere on any device. With an intuitive interface, it's easy to perform any management tasks. For instance, you can remotely configure, update, and troubleshoot devices, helping save time and effort. Additionally, this stress-free device management software offers easy user management and includes pre-defined roles.

- > Remotely manage all your devices
- > Update device software automatically
- > Configure edge analytics
- > Ensure security and data confidentiality
- > Intuitive and always accessible



AXIS Device Manager Edge

System features

Supported devices

A-line: series 8xxx – 91xx, 92xx
C-line: series 1xxx – 8xxx
D-line: series 1xxx – 4xxx
FA-line: series 1xxx – 5xxx
F-line: series 1xxx – 4xxx
I-line: series 1816
M-line: series 1xxx – 8xxx
P-line: series 1xxx – 8xxx
Q-line: series 1xxx – 8xxx
V-line: series 5915, 5925, 5938

Device management

Discover devices
Add devices to sites
Schedule device software upgrades
Access a device's interface with one click
Configure edge analytics through the device interface
Export device inventory report
View site logs
Monitor device connectivity status
Monitor edge analytics status
Monitor end of software support

Warranty

Monitor device warranties
Monitor device discontinuation date

Administration

Manage organizations
Identity and access management (IAM)

Security

Connect using Axis Secure remote access
System changes logged

Scalability

Suitable for managing thousands of Axis devices.
Connect to My Systems for a site-by-site overview. See <https://dm.mysystems.axis.com/>

General

Languages

English, Czech, French, German, Italian, Japanese, Korean, Russian, Spanish, Arabic, Chinese (Simplified), Chinese (Traditional), Dutch, Finnish, Persian, Polish, Portuguese (Brazil), Romanian, Swedish, Thai, Turkish, Vietnamese, and Hebrew

System requirements

Software

Firmware 6.50 or later
For a list of all supported operating systems, see the release notes available in the client.

Minimum requirements

AXIS Device Manager Edge desktop app:

Windows 10 Enterprise/Pro, Win Server 2019/2022
x86-64 Processor (Intel / AMD x64 Processors)
2GB RAM
100Mbps Wired Ethernet
1GB free storage

Edge host:

Windows 10 Enterprise/Pro, Win Server 2019/2022
x86-64 Processor (Intel / AMD x64 Processors)
2GB RAM
100Mbps Wired Ethernet
1GB free storage

AXIS Device Manager Edge and edge host:

Windows 10 Enterprise/Pro, Win Server 2019/2022
4GB RAM
100Mbps Wired Ethernet
2GB free storage