



AXIS TF2001

Installation guide
Guide d'installation
Installationsanleitung
Guida all'installazione
Guía de instalación
インストールガイド
Guia de instalação
Руководство по установке
설치가이드
安裝指南
Panduan instalasi
Kurulum kılavuzu



1x




1x





2x









2x



1.1




i




1.2




AXIS F2180-TE
AXIS F2137-RE
AXIS F2135-RE
AXIS F2115-R
AXIS F2107-RE
AXIS F2105-RE
Installation guide




1.3



1.4




1.5




2.1






AXIS F2180-TE
AXIS F2137-RE
AXIS F2135-RE
AXIS F2115-R
AXIS F2107-RE
AXIS F2105-RE
Installation guide



2.2





i





3.1


i





4.1



4.2





4.3



5.1

i





3444744

2025-10 (M2.2)

© 2025 Axis Communications AB