

## INSTALLATION IN A NETWARE 3.x ENVIRONMENT

=====

This document describes how installation of AXIS 560/660/570/670 can be made in the bindery of a file server with AXCFG and PCONSOLE.

1. Start a NetWare client and login as SUPERVISOR.
2. Start AXCFG (for information see AXCFG).
3. Login (normally with 'root' and 'pass') and go to NETWARE MENU.
4. In the PSERVER\_BINDERY1 parameter, specify the name of the file server where the printer and print queue will be defined.
5. Exit AXCFG and start PCONSOLE.
6. Select "Print Queue Information", select a queue or create a new one.
7. Return to "Available Options" menu.
8. Select "Print Server Information", press <INS> and type the print server name (by default AXIS followed by the six last digits of the serial number found at the bottom of the print server).
9. Select the print server, "Print Server Configuration", "Printer Configuration and then "Printer 0". Press Insert and name the printer, then select "Type".
10. Select "Parallel,LPT1", "Parallel,LPT2" or "COM1" depending on which port you want to use on the AXIS box.
11. Exit "Printer Configuration" and save.
12. Select "Print Server Configuration", and then "Queues Serviced by Printer".
13. Select the printer, press <INS> and select your queue.
14. Exit PCONSOLE
15. Restart the print server.

Aug 12, 1996 kst